



CHLORINE TESTKIT



MARINE CARE BV Mozartlaan 3 3144 NA Maassluis The Netherlands T. +31 (0)10 2950342 F. +31 (0)10 2950345 E. supply@marinecare.nl





Some reagents required for tests shown in this booklet are classed as hazardous and as such, a minimum protection of gloves (rubber or plastic) and safety goggles/spectacles or facemask **MUST BE WORN**.

In addition please note and observe the Risk and Safety phrases on each reagent container and follow handling guidelines as instructed.

GENERAL NOTES

- ⇒ Avoid contact with skin or eyes
- ⇒ In case of contact with skin or eyes rinse immediately with plenty of running tap water, and seek medical attention
- ⇒ Seek attention if irritation persists
- ⇒ In case of ingestion, wash the mouth out thoroughly with water, try to vomit and seek medical attention

MARINE CARE BV
Mozartlaan 3
3144 NA Maassluis
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. supply@marinecare.nl
W. www.marinecare.nl

FREE & TOTAL CHLORINE (0 - 1 mg/l)

Note:

- 1. Take care not to shake or aerate the sample
- 2. Store the reagents in a cool and dry place mg/l = ppm

mg/r = ppm							
Fill one (1) tube with 10 ml of sample. Place in the left side of the comperator	Add one DPD N0.1 tablet to the order tube containing a small amount of the sample	Fill the tube to the 10 ml mark fit the cap and mix thoroughly Place in right side Of comparator	Rotate the disc until colour match is obtained Record disc reading of Free Chlorine	Take the right hand tube from the comparator Add one (1) DPD N0.3 tablet fit the cap and mix thoroughly Place in right side Of comparator	Rotate the disc until colour match is obtained Record disc reading of Total Chlorine		

Combined Chlorine in mg/l or ppm = Total Chlorine - Free Chlorine

Chlorine Testkit	11914		
Description	Amount	Article number	
Free Chlorine 0 - 1 mg/l			
Reagent DPD1, 100 tablets	1	11940	
Reagent DPD3, 100 tablets	1	11941	
Tablet crusher	1	11992	
Test tube square10 ml, with lid	2	11993	
Comparator	1	11994	
Chlorine Disc 0 - 1 mg/l	1	11995	





- ⇒ Contact us for advise
- ⇒ E-mail us all test figures over a period of at least 3 months

MARINE CARE BV
Mozartlaan 3
3144 NA Maassluis
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. supply@marinecare.nl
W. www.marinecare.nl