



CARECLEAN QUICKSPLIT

A solvent based quick separating oil and grease remover suitable for use in conjunction with oily water separators

- Biodegradable
- Quick Separating
- Multipurpose
- High flashpoint
- Approved by:
> Marinfloc

DESCRIPTION

Careclean QuickSplit is a special degreasing agent for the removal of oil and grease from machines and motor parts, transmissions, ball bearings, gear wheels, metal parts, floorplates and bulkheads in the engine room. The cleaning emulsion with water and oil breaks up within a very short period.

ADVANTAGE

- inherently biodegradable
- good cleaning properties
- odorless
- quick acting
- suitable for the removal of most mineral oils, fats, greases and preserving agents
- safe to use on all common metals, painted surfaces, epoxy and zinc-silicate coatings
- has the approval of major manufacturers for use in their oily water separators

APPLICATIONS

Careclean QuickSplit is used to clean machinery, floor plates and bulkheads in engine rooms.

DIRECTIONS FOR USE

General maintenance

For cleaning in engine rooms etc., Careclean QuickSplit is used undiluted. Dampen the surface to be cleaned and let the product act for 5 - 60 minutes. Brush the surfaces occasionally and finally rinse them thoroughly with water at 50 - 60 °C. For heavier contamination we recommend Careclean Degreaser HD Split.

discover the difference

MARINE CARE BV
Mozartlaan 3
3144 NA Maassluis
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. supply@marinecare.nl
W. www.marinecare.nl



Bilge Tanks

To be used as a spotcleaner to decrease the amount of slops. Spray the contaminated surfaces until they are thoroughly dampened with undiluted Careclean QuickSplit. Let the product act for 5-60 minutes, then rinse thoroughly with water at 50 - 60 °C.

Immersion baths

Careclean QuickSplit is applied undiluted at ambient temperature or up to a maximum of 55 °C in a heated bath. Soak components for several hours, remove from the bath and rinse thoroughly with a waterjet.

Note

The use of emulsifying products will affect the separating properties of Careclean QuickSplit.

DOSAGE

All types of cleaning undiluted

PROPERTIES

Article number	14103
pH	Not applicable
Density	0,76 g/cm ³
Flashpoint	> 62 °C
Physical state	Liquid

APPROVALS

Marinfloc Approved OWS Compatible

For detailed information on safety and health, please refer to the Material Safety Data Sheet MSDS and/or product label.

CARECLEAN QUICKSPLIT

- Biodegradable
- Quick Separating
- Multipurpose
- High flashpoint
- Approved by:
> Marinfloc

discover the difference

MARINE CARE BV
Mozartlaan 3
3144 NA Maassluis
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. supply@marinecare.nl
W. www.marinecare.nl