

CARECLEAN SEPARATOR

Acidic cleaning product for cleaning of stainless steel separator discs and separator bowls

- Eco-friendly
- Biodegradable
- Highly effective
- Non Toxic
- Approved by:
> Marinfloc

DESCRIPTION

Careclean Separator is a strong acid and solvent based cleaner for fuel- and lubrication-oil separator discs and bowls.

ADVANTAGE

- Strong cleaning agent specially developed for cleaning stainless steel separator discs and bowls
- One step cleaning for hardness scale and carbonized oil
- Retains strong degreasing properties
- Contains no petroleum solvents
- Non-flammable

APPLICATIONS

Contaminants found on separator discs mostly consists of hardness salts (calcium carbonate etc.) and partly carbonized oil. The combination of dissolving agents, acids and surface active agents makes it possible to clean the separator discs quickly without brushing.

After cleaning the metal surface is passivated by the acid in the product.

DIRECTIONS FOR USE

Fill a stainless steel or plastic container with pure Careclean Separator. Immerse the stainless steel discs in the container and let the product act for 30 minutes up to a maximum of 2 hours. Heating the product is not necessary. Do not put the discs closely packed into the liquid, but take care that there is enough space between them, so the product can do a proper job. Remove the discs from the bath (wear rubber gloves) and rinse with a powerful waterjet.

The cleaned separator discs are ready for immediate use.

discover the difference



DOSAGE

Separator Cleaning undiluted

PROPERTIES

Article number 14204
pH (1 % solution) 1,0
Density 1,04 g/cm³
Flashpoint Not applicable
Physical state Liquid

APPROVALS

- Marinfloc Approved OWS Compatible

For detailed information on safety and health, please refer to the Material Safety Data Sheet MSDS and/or product label.

CARECLEAN SEPARATOR

- **Eco-friendly**
- Biodegradable
- Highly effective
- Non Toxic
- Approved by:
> Marinfloc

discover the difference

MARINE CARE BV
Mozartlaan 3
3144 NA Maassluis
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. supply@marinecare.nl
W. www.marinecare.nl